

Cream Gel with PolyAquil 2W

Phase A	INCI Name	% w/w	Grams
Water	Water	79.90	199.75
FSS Sodium Phytate	Sodium Phytate	0.10	0.25
FSS Glycerin	Glycerin	3.00	7.50
Phase B			
PolyAquil 2W	Polyglyceryl-2 Stearate, Glyceryl Stearate, Stearyl Alcohol	4.00	10.00
FSS Repair Oil Complex	Helianthus Annuus (Sunflower) Seed Oil & Glycine Soja (Soybean) Oil & Anthemis Nobilis Flower Oil & Lavandula Angustifolia (Lavender) Oil & Rosmarinus Officinalis (Rosemary) Leaf Oil & Calendula Officinalis Flower Extract & Tocopheryl Acetate & Retinyl Palmitate & Bisabolol	3.00	7.50
Phase C			
FSS Revital-Eyes	Water, Lactobacillus Ferment Lysate, Camellia Sinensis Leaf Extract, Punica Granatum Extract, Caffeine	2.00	5.00
FSS Dermal Respiratory Factor Advanced PF	Water, Saccharomyces Lysate Extract	2.00	5.00
FSS Ferula Foetida Extract	Water, Ferula Foetida Root Extract	2.00	5.00
FSS Party Face Pom	Water, Punica Granatum Extract, Citrus Aurantium Dulcis (Orange) Flower Extract	2.00	5.00
Geogard Ultra (Powder)	Gluconolactone, Sodium Benzoate	1.00	2.50
PhytoScents Goji Berry	Lycium Barbarum Fruit Extract	0.50	1.25
PhytoScents Pomegranate	Punica Granatum Extract	0.50	1.25
		100.00	250.00

Procedure:

1. Combine Phase A and mix until uniform. Heat to 75-80C.
2. At temp, add Phase B to Phase A one by one until uniform after each addition. Cool with mixing to 50-55C.
3. At temp, homogenize at 2000-2500 RPM for 5-10 minutes.
4. Cool with mixing to 20-25C.
5. At temp, add Phase C to Phase AB with mixing until uniform.
6. Adjust pH to 5.0-5.5, with 50% Citric Acid/Water solution.

All products Should undergo stability testing and Microbial/Challenge Testing. These formulations are intended for use as starting formulas and may be altered as needed

Formulator Sample Shop makes no warranty, express or implied, including any warranty of merchantability, non-infringement or fitness for a particular purpose, concerning the composition or use of these formulas. Users assume all risks and responsibility resulting from such use and the handling, use, storage, transportation, sale or resale of any products made therefrom. Formulator Sample Shop assumes no liabilities or obligations for the technical content found herein regarding formulas or the results obtained therefrom Users rely on this information at their sole risk and should make their own, independent determination as to the suitability of any product for a particular use. User waives all claims against Formulator Sample Shop for damages, including consequential and punitive damages, even if Formulator Sample Shop has been advised or has notice of the possibility of such damages, and User agrees to defend and indemnify Formulator Sample Shop against any loss, damages, liability, cost and expense relating to the use of the formulas and/or the handling, use, storage, transportation, sale or resale of any products made there from.